



Assembly Instructions W280

Ready to Assemble Lectern

WARRANTY

Limited Six (6) -Year Warranty

AmpliVox warrants this product to be free from defects in materials and workmanship (subject to the terms set forth below) for a period of six (6) years from the date of purchase ("Warranty Period").

During the Warranty Period, AmpliVox will repair or replace (at AmpliVox discretion) this product or any defective parts ("Warranty Service").

Repair or replacement under the terms of this warranty does not give right to any extension or a new beginning of the period of warranty.

CLAIMS UNDER THE WARRANTY

To obtain Warranty Service, **contact AmpliVox (800-267-5486)** to be assigned a **Return Authorization number (RA#)**. After receiving a RA#, the defective unit is to be returned to AmpliVox in either its original packaging or packaging affording an equal degree of protection. You will bear the cost of shipping the product to AmpliVox. If the product is covered by the warranty, AmpliVox will bear the cost of shipping product back to you after the completion of service under this warranty.

Return shipping will be charged to you for products not covered by the warranty or requiring no warranty repair.

The following information must be presented to obtain Warranty Service: **(a)** the RA# must be clearly and legibility marked on the outside of shipping carton, **(b)** proof of purchase, which clearly indicates the name and address of the seller, the date of purchase and the product type, which is evidence that this product is within the Warranty Period. Please further include **(c)** your return address, **(d)** daytime telephone number, and **(e)** reason for return.

LIMITATION OF WARRANTY

This warranty is only valid for the original purchaser and will automatically terminate prior to expiration if this product is sold or otherwise transferred to another party. The warranty provided by AmpliVox in this statement applies only to products purchased for use, and not for resale. It does not apply to open box purchases, which are sold "as is" and without any warranty. Specifically exempt from warranty are limited-life consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions, modular plugs, ear tips, decorative finishes, batteries, and other accessories. This warranty is invalid if the factory-applied serial number, date code label, or product label has been altered or removed from this product.

This Warranty does not cover cosmetic damage or damage due to misuse, abuse, negligence, Acts of Nature, accident, disassembling or modification of, or to any part of, the product. This Warranty does not cover damage due to improper operation, maintenance or installation, or attempted repair by anyone other than AmpliVox. Any unauthorized repairs will void this warranty.

REPAIRS OR REPLACEMENTS AS PROVIDED UNDER THIS WARRANTY ARE THE EXCLUSIVE REMEDY OF THE CONSUMER. AMPLI VOX SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PRACTICAL PURPOSE.

NOTE! This warranty gives you specific legal rights. You may have other rights which vary from location to location. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or implied warranties, so the above exclusions may not apply to you. This warranty does not affect your legal (statutory) rights under your applicable national or local laws.



Dispose of the product according to local standards and regulations

Jan, 2014




Thank you for choosing the **W280 Lectern** from AmpliVox Portable Sound Systems.

We are excited in introducing this truly unique lectern. Our lectern combines flexibility with functionality. Please refer to this user guide as you enjoy the unique capabilities of another quality product from AmpliVox Portable Sound Systems.


We encourage you to visit our website **www.ampli.com** to register your product for its warranty coverage, sign up to receive our newsletter, download our catalog, and learn more about the complete line of AmpliVox audio visual products, including portable PA systems, and other lecterns.

PANEL DESCRIPTIONS



HARDWARE LIST

ITEM	DESCRIPTION	QTY
A	Cam Lock	14
B	Glides	4
C	Dowel Pins	6



GETTING STARTED

Unpack all panels from shipping box. Locate accessories and open.

TOOLS NEEDED: Philips Screw Driver, Rubber Mallet

CAM LOCK AND DOWEL PIN INSTALLATION

- Locate Panels (1) (2) (3) (4) (5), including items (A) (B) and (C). Lay all the panels on a flat surface with the side that has all the cutouts facing up.
- Take one item (A) Cam Lock, and press into each cutout with your fingers or softly tap in with rubber mallet.
- Repeat on all panels.
- On the edges of the front panel and the shelf, you will see holes for the dowel pins, item (C). Insert a dowel pin into each hole.
- Set all panels aside.
- With the Front Panel (1) still on a flat surface take one of the side panels (2) (4) and align the holes with the dowel pins and cam locks sticking out from Panel (1). Tap in place. Lock cam locks.
- Lock panels in place by rotating cam lock with screw driver, turning lock clockwise until you can not turn any more.
- Next take the shelf (5) and align the dowel pin and cam locks with the holes in the side panel. Tap in place. Lock cam locks.
- Take the other side panel, align the holes with the dowel pins and cam locks sticking out from Panel (1). Tap in place. Lock cam locks.
- To complete the assembly, take the reading surface panel (3) and align the four holes with the cam locks sticking out from the two side panels. Tap in place. Lock cam locks.
- Lastly, take the four tack glides (B) and attach to the bottom of the two side panels in four places.
- Stand lectern up.

